
## Send from Designer Epic<sup>™</sup> & Brilliance<sup>™</sup> 80: Windows

## Configuring your Software and Embroidery Machine


- 1 Enter your mySewnet<sup>™</sup> details in the Connection tab of PREMIER+<sup>™</sup> 2 Configure.
  - You can also name your computer in the Connection tab.
- 2 Ensure that PREMIER+<sup>™</sup> 2 Machine is running in the system tray.
- **3** Go the the embroidery machine.

blibes A	ppearance Imp	port Export Connection	
mySewm	et"		
	E-mail Address:	Jane Øbramblecottage.com	Sign out
	Password:	•••••	Sign in
	Status:	Not signed in.	
Denies	an it can charts be	ave a mySeynet <sup>**</sup> Account.	
		f you've forgotten it.	
Compute			
Iden	tify this compute	er as: Jane's Laptop	
Name and	Activation		
		is activated via network	
	Serve	er 10-	Refresh
			nencon

4 At the embroidery machine, tap the Cloud button at the top and ensure that you are signed in to mySewnet<sup>™</sup>.



5 Deselect JoyOS advisor ™ 🗾, then select Settings 🔞 and Machine Settings.



6 In Machine Settings, give your machine a Nickname.

	> ● ○ ○ ■ ○ ○ ■ ○	🗢 🕒 💽 ? 💿 🖬 • 🗌
Settings	Settings	Settings
Machine Settings	Machine Settings	Machine Settings
Language Dansk Doctoh Dettoh Tranpis Italiano Hederlands Procoiloani Seeda #52	Enter New Machine Nickname	Language Danak Doutsch Dirgith François taliano Hederlands Procesiocas Sensia # 52
Audio Volume 🔰 🔶 📢	с с с с с с с с с с с с с с с с с с с	Audio Volume 🖬 🔶 📢
Audio Repeat When salected the coads worring for some alors or extension pop-up messages are repeated and the pop-up is confirmed; e.g. or thread terral worring.		Auclio Repeat. Messaverate and he pop-up activities or attention pop-up and any activities of the pop-up and the pop-up or activities of e.g. at the word break eventse.
Machine Nickname Machine Name	Machine Nickname Machine Name	Machine Nickname Jane's Epic
Lock Screen The screen to locked when inactive.		Lock Screen The screen it locked when inocitive.
LED Work Light Brightness 🔆 — — — — — — — — — — — — — — — — — —		LED Work Light Brightness
Units OMEmetar Indi		Units  Units  Milmear  noh
Cleck	Q W E R T Y U I O P A S D F G H J K L Z X C V B N M	Cleck Cleck TreeSar Locar Clock on Di Zowar format Di Zowar format Di Zowar format
Automatic time Marcul time	123 00 . , • [•	Automatic time Manual time

7 Close Settings.


2

## Sending to and from an Embroidery Machine


- 1 If needed, deselect JoyOS advisor <sup>™</sup> [2].
- 2 Tap Embroidery mode 🔲 , and then load an embroidery.




3 In the machine screen, choose the Send Design 🕢 option.



The machine will send only the selected design. Ensure that your design is selected. The send button is not available if nothing is selected. 4 Select the computer to send to, then send the embroidery. The embroidery will open in a new PREMIER+<sup>™</sup> 2 Embroidery window.




5 When you have adjusted the embroidery, save the changes to your computer.



You can also use PREMIER+<sup>™</sup> 2 Modify to adjust and send embroideries to your machine.

4

6 You can then use Send to Machine via mySewnet<sup>™</sup> to return the edited embroidery to your machine for stitching out.



All designs within the hoop on the computer screen will be sent.

If the machine is still open from when you sent the embroidery, the new version will be placed on the screen with the original.

Documentation correct as of November 2018:

- PREMIER+<sup>™</sup> 2 Embroidery version 12.3
- HV Designer Epic<sup>™</sup> version Release 304
- HV Designer Brilliance<sup>™</sup> 80 version Release 65

VIKING and PREMIER+ are trademarks of Singer Sourcing Limited LLC. All trademarks are used under license of Singer Sourcing Limited LLC. © 2018 Singer Sourcing Limited LLC. All rights reserved.